




Decor 408517 / 402212
Fuchsia



Decor 408519 / 402211
Denim



Decor 408525 / 402201
New Red




Decor 408526 / 402209
Dark Brown



Decor 408527 / 402207
Apple Green



Decor 408528 / 402220
Turquoise




Decor 408529
Beige



Decor 408531
Lavender

Spülmaschinenfest
Dishwasher safe
Résistant au lave-vaisselle
Resistente al lavaggio
in lavastoviglie

Mikrowellengeeignet
Microwave safe
Adapté aux micro-ondes
Adatto alla cottura nel
forno a microonde



Decor 800001
Weiß




Decor 408500 / 402214
Light Blue




Decor 408501 / 402217
Red




Decor 408502 / 402202
Yellow



Decor 408503 / 402213
Green




Decor 408505 / 402203
Orange



Decor 408510 / 402206
Pastel Blue



Decor 408511 / 402205
Pastel Yellow



Decor 408512 / 402204
Pastel Green

Spülmaschinenfest
Dishwasher safe
Résistant au lave-vaisselle
Resistente al lavaggio
in lavastoviglie

Mikrowellengeeignet
Microwave safe
Adapté aux micro-ondes
Adatto alla cottura nel
forno a microonde